


VLT Series 600 Watt True Sine Wave Inverter



Models

VLT12-600

VLT24-600

TABLE OF CONTENTS

1	INTRODUCTION	3
2	IMPORTANT SAFETY INSTRUCTIONS	3
2.1.1	General Safety Precautions	3
2.1.2	Precautions When Working With Batteries	4
3	SPECIFICATIONS AND FEATURES.....	5
3.1.1	Specifications	5
3.1.2	Front Panel	6
3.1.3	ON / OFF Control Switch	6
3.1.4	Remote Control Terminal	6
3.1.5	DC Input Level LED	6
3.1.6	AC Load Level LED	7
3.1.7	AC Output GFCI Duplex Receptacle	7
3.1.8	Rear Panel	8
3.1.9	Single Wire Remote Control	8
3.1.10	DC Input Terminals	9
3.1.11	Chassis Ground Bonding Lug	9
3.1.12	Fan	9
3.1.13	Measurements	9
4	INSTALLATION	10
4.1.1	DC Wiring Considerations	10
4.1.2	DC Cable and Fuse Sizing Chart	11
4.1.3	DC Wiring Installation Procedure	11
5	TROUBLESHOOTING	12
6	MAINTENANCE	12

1 INTRODUCTION

Thank you for purchasing a Vanner 600 Watt VLT SERIES Inverter. We are confident that you will be satisfied with the inverter's performance and its many features. With proper installation and care, you can look forward to years of service from this high performance product.

This document will describe the operation, technical specifications and installation procedures.

2 IMPORTANT SAFETY INSTRUCTIONS



Electrocution hazard exists



Fire hazard exists



A potentially dangerous condition



Explosive hazard exists



Corrosive hazard exists

To get the most out of the power inverter, it must be installed and used properly. Please read the instructions in this manual before installation. Keep this manual for future reference.

2.1.1 General Safety Precautions



Do not expose the inverter to rain, snow, spray, or dust. To reduce risk of hazard, do not obstruct the ventilation openings. Do not install the inverter in a zero-clearance compartment. Overheating may result.



To avoid a risk of fire and electric shock, make sure the wiring is in good electrical condition and is proper gauge. Do not operate the inverter with damaged or substandard wiring.



This equipment contains components that can produce arc or sparks. To prevent fire or explosion, do not install in compartments containing batteries or flammable materials or in locations which require ignition protected equipment. This includes any space containing gasoline-powered machinery, fuel tanks, or joints, fittings, or other connection between components of the fuel system.

2.1.2 Precautions When Working With Batteries



If battery acid contacts skin or clothing, wash immediately with soap and water. If acid enters eye, immediately flood eye with running cold water for at least 20 minutes and get medical attention immediately.



Never smoke or allow a spark or flame in vicinity of battery or Engine.



Do not drop a metal tool onto the battery. The resulting spark or short-circuit on the battery or other electrical part may cause an explosion.




Remove personal metal items such as rings, necklaces, and watches when working with a lead-acid battery. A lead-acid battery can produce a short-circuit current high enough to weld a ring or the like to metal, causing severe burns.

3 SPECIFICATIONS AND FEATURES

3.1.1 Specifications

	Model Number	
SPECIFICATIONS	VLT12-600	VLT24-600
AC Power Output		
Rated Continuous Output	600 Watts	
Surge Rating (3S)	800 Watts	
Output Waveform	True Sine Wave	
Total Harmonic Distortion	< 3% THD	
Output Voltage	120 VAC +/- 3%	
Output Frequency	60 Hz	
AC Output Wiring Method	GFCI Duplex Receptacle	
Maximum, Efficiency %	88	90
DC Input Voltage	12V Nominal	24V Nominal
DC Input Voltage Range	11.5 to 16.0	23.0 to 32.0
Low DC voltage Shutdown / Restart	11.3 / 13.5	22.5 / 26.5
High DC voltage Shutdown / Restart	16.3 / 15.8	32.6 / 31.5
DC Input Current		
Inverter ON with no AC load	< 1A	
System		
Protection	Overload, Short Circuit, Reverse Polarity (internal fuses), Over/Under Input Voltage, Over Temperature	
Safety	UL458	
Remote Control	ON/OFF Control by customer supplied external switch	
Ambient Operating Temperature	-25 +50°C (-13 to +122°F)	
Storage Temperature	-30 to +70°C (-22 to 158°F)	
Fan Cooling	Thermostatically controlled cooling fan	
Enclosure	Painted aluminum	
Dimensions (L x W x H)	11.0" L x 7.25" W x 3.0" H	
Weight	6.6 pounds	

3.1.2 Front Panel



3.1.3 ON / OFF Control Switch

The ON/OFF Switch must be in the ON position when using Remote Control.


3.1.4 Remote Control Terminal

A green two-terminal connector located on the rear panel allows remote ON/OFF control of the inverter by a customer-supplied ON/OFF switch. The connector can be removed from the inverter by pulling the connector outward. The two upward facing screws are used to tighten the compression terminals for attachment of the signal wire(s). Torque to 4 lb-in max.

Standard Operation (no remote control)

The inverter is shipped with a jumper connecting terminals Vout and Vin. With the jumper in place (remote control not being used) the inverter is fully functional using the ON/OFF control switch located on the front of the inverter.

3.1.5 DC Input Level LED



3.1.6 AC Load Level LED

LED Display and Color	Approximate Load Condition
Dark	0 ~ 30W
Green	30W ~ 200W
Orange	200W ~ 450W
Red	450W ~ 580W
Red Blink	Over 580W
Red Fault Led – Solid when unit has shut down for over load.	

3.1.7 AC Output GFCI Duplex Receptacle

The AC output neutral conductor is connected to AC ground and inverter chassis ground inside the inverter. This conforms to National Electrical Code requirements that separately derived AC sources (such as inverter and generators) have their neutral conductors tied to ground in the same way that the neutral conductor from the utility is tied to ground at the AC breaker panel.




Do not connect AC neutral to AC ground downstream of the GFCI.
This would cause the GFCI to trip.




Never connect the inverter output to another AC power source such as a generator or utility power. The inverter would be destroyed.

3.1.8 Rear Panel



3.1.9 Single Wire Remote Control



Remote Control via customer-supplied SPST switch: If it is desired to remotely control the inverter from a customer-supplied remote switch, remove the jumper connecting terminals Vout and Vin. Supply a 12v (24v signal on 24v units) continuous signal to terminal Vin to turn the inverter ON. The source of the 12v signal can be battery voltage for single-wire remote control or terminal Vout for two-wire-remote-control.

A common remote control arrangement uses a "hot in run" circuit from the vehicle fuse panel for the voltage signal. This arrangement automatically turns the inverter ON when the vehicle is running and automatically turns the inverter OFF when the vehicle is turned OFF.

Vin Details

Vin will draw approximately 0.4 amps continuous while holding the inverter ON. If Vout is *not* used as the remote control signal, use a 5 amp fused circuit for the Vin remote control signal.

Vout Details

When using Vout as the remote control voltage source, install a 2 amp fuse within 12" of the inverter.

The inverter will be damaged if Vout comes into contact with battery negative

3.1.10 DC Input Terminals

- DC Input terminals are for the included 6AWG ring terminals. The ring terminal entry is limited to a maximum of 4AWG wire.
- Connect DC Input Terminals to a 12v battery (24v battery for 24v units). (+) is positive,(-) is negative. **Reverse polarity connection will blow the internal fuses and may cause permanent damage to the inverter.**

3.1.11 Chassis Ground Bonding Lug

Connect Chassis Ground Bonding Lug to vehicle chassis using 12AWG or larger copper wire.



WARNING!


Operating the inverter without a proper ground connection may cause an electrical hazard.

3.1.12 Fan

Do not obstruct the rear fan exhaust or front ventilation intake openings. Allow at least 3 inches of clearance for airflow.

3.1.13 Measurements

VLTxx-600 Mounting Bolt Pattern



4 INSTALLATION

Inverter Installation Considerations

- **Mounting:** Locate a flat secure, dry, horizontal or vertical surface large enough to mount the inverter. The location should be as close to the battery as practical, usually within six feet, but not in the same compartment and should provide adequate ventilation while the inverter is operating. The location must be clean, dry and free from road spray, dripping water or other moisture contamination.
- **Cooling Fan Clearance:** The mounting location must allow unobstructed airflow for cooling. Allow a minimum clearance of 3 inches on the front and back of the inverter. The Cooling Fan is thermostatically controlled. Obstruction of the fan exhaust or the front intake vents will diminish the inverter output capacity due to overheating.

4.1.1 DC Wiring Considerations

-  Do not connect the 12V model to a 24V battery. The unit will be destroyed immediately. Operation of the inverter without a proper ground connection may result an electrical safety hazard. Damage caused by reversed polarity will void warranty.
-  **A DC FUSE IS REQUIRED** to protect the DC cables in case of a short circuit. The wiring of the inverter installation should conform to the National Electric Code (NEC) and any other state or local codes in effect at the time of installation. Article 551 of the NEC requires any DC cable from a battery, which measures longer than 18 inches along its length, be protected by a fuse.
-  **BE AWARE**, as a large number of capacitors become charged upon completion of the DC circuit, **THERE WILL BE A LARGE SPARK** when the last battery connection is made. The spark is normal and will occur every time the batteries are connected. It is advisable to make the last DC connection at the inverter, not at the battery, to reduce the risk of battery explosion.
- To minimize electromagnetic radiation that could interfere with sensitive electronics, route the AC output wiring and DC power wiring with as much physical separation as possible from low voltage wiring such as audio and video signal wires. Route the DC positive and negative cables as close together as possible and use cable ties to keep them together.
- If passing through steel or other ferrous metal walls, the DC input cables need to pass through the same hole to prevent causing a transformer effect. If two holes are required, cut a slot to connect the two holes to prevent heating of the ferrous metal.
-  **Proper DC cable size is critical** for the performance and safe operation of the inverter system. *The DC Cable and Fuse Sizing Chart* shows the minimum cable sizes recommended. These sizes allow a ½ volt maximum voltage drop at maximum inverter capacity and will insure optimum inverter performance. DC cable to be used with these fuse sizes should be ***minimum*** insulation temperature rating of 105°C and voltage rating of 600V.
- DC cables should be as short as possible.
- Do not use the vehicle chassis as the DC negative conductor. The negative cable should be the same size as the DC positive cable and should be connected directly to the battery negative terminal.

4.1.2 DC Cable and Fuse Sizing Chart

Model Number	VLT12-600	VLT24-600
	Distance from battery to inverter in feet (Total circuit length is 2 times the distance.)	
Wire Size		
8	6.5	13.5
6	10.0	20
4	16.0	20
Fuse Rating	80 Amp	60 Amp
Fuse Part Number	013910	013909
Fuse Holder Part Number	012992	
Ring Terminal 4 AWG, 1/4 stud, narrow	011973	

4.1.3 DC Wiring Installation Procedure

- Verify the Power ON/OFF Switch is in the OFF position before connecting inverter to the battery.
- Route the negative DC cable to the battery. Verify cable polarity before proceeding. The fuse will be blown and inverter may be damaged if the DC cables are reversed. Route the positive DC cable to the fuse and then to the battery. Protect cables with loom and use grommets or other appropriate means where cables may contact hard, sharp edges.
- Connect Chassis Ground Bonding Lug to the vehicle chassis and/or earth ground using 8AWG or larger copper wire. (The wire must be sized to safely carry DC current as needed to blow the DC fuse located near the battery in the inverter's positive DC input cable.)

5 TROUBLESHOOTING



WARNING! Do not open or disassemble the Inverter. Attempting to service the unit yourself may result in a risk of electrical shock or fire, and will void warranty.

Problems and Symptoms	Possible Cause	Solutions
<i>No AC output voltage</i>		
Led Blinking Red Fast.	High DC input voltage.	Check input voltage. Reduce input voltage.
Led Blinking Red Slowly.	Low DC input voltage.	Recharge battery. Check connections and cable.
No Led's on	Over temperature shut down	Improve ventilation. Make sure inverter ventilation openings are not obstructed. Reduce ambient temperature. Unit will automatically turn on when it cools.
No LED's on	Blown DC input fuse	Replace inverter DC input fuse
Fault Led ON Solid Red	Overload, short circuit	Remove AC load. Check AC wiring for short circuit.
Unit with remote immediately shuts down following power up sequence. Unit displays the input level led and a solid fault led.	Blown fuse on inverter positive DC input.	Replace inverter DC input fuse.

6 MAINTENANCE

Very little maintenance is required to keep the inverter operating properly.

- Clean the exterior of the unit periodically with a damp cloth to prevent accumulation of dust and dirt.
- At the same time, verify the battery and fuse connections are clean and tight.
- Test and reset the GFCI monthly.

Vanner Incorporated
4282 Reynolds Drive
Hilliard, Ohio 43026

Ph: 800-AC POWER
Ph: 614-771-2718
Fax: 614-771-4904
www.vanner.com

Manual P/N: D916054-B
July 2016