



ITEM NO.	QTY.	PART NUMBER	DESCRIPTION
1	1	CM002531	BRACKET, MOUNT, 55 DEG. 5" LOWER OFFSET BASE W/ SLOTS
2	1	10-003389	BRACKET, MOUNT, HDM, BASE, UNIVERSAL
3	4	GSM31006	WASHER, 5/16" FLAT, SAE ZP
4	4	GSM31027	WASHER, 5/16" LOCK, ZP
5	4	GSM33011	SCREW, 5/16-18 X 3/4"
6	4	GSM30007	NUT 5/16-18 HEX ZP
7	4	GSM31006	WASHER, 5/16" FLAT, SAE ZP
8	4	GSM31019	WASHER 5/16 X 1 1/2 FENDER ZP
9	4	GSM31027	WASHER, 5/16" LOCK, ZP
10	4	GSM33014	SCREW 5/16-18 X 1 1/2 HHCS ZP

#### INSTALLATION INSTRUCTIONS

1. PLACE THE BASE IN THE DESIRED LOCATION.
2. MARK AND DRILL (4) BASE HOLES. BE SURE THERE IS NOTHING THAT CAN BE DAMAGED BY THE DRILLING OPERATION.
3. SECURE THE MOUNT TO THE FLOOR OF THE VEHICLE WITH SUPPLIED HARDWARE.
4. ATTACH LOWER OFFSET TO BASEPLATE WITH 5/16" BOLTS, LOCK WASHERS AND FLAT WASHERS (ANGLE TOWARDS CENTER OF VEHICLE.)
5. FOLLOW GENERAL INSTRUCTIONS FOR POLE AND UPPER MOUNT PARTS.

<b>HAVIS</b> HAVIS, INC.		75 JACKSONVILLE RD. WARMINSTER, PA. 18974 1-800-524-9900
TITLE: UNIVERSAL HDM BASE		
DO NOT SCALE DRAWING		
SIZE <b>A</b>	DWG. NO. C-HDM-136-INST	REV 3-13
WEIGHT (LB): 6.478	SCALE: 1:8	SHEET 1 OF 1