



ITEM NO.	QTY.	PART NUMBER	DESCRIPTION
1	1	10-002541	BRACKET, MOUNT, 45 DEG. 5" LOWER OFFSET BASE W/SLOTS
2	2	10-004011	SPACER, 1.5"
3	1	30-004010	WELDMENT ASSY F250
4	4	GSM31006	WASHER, 5/16" FLAT, SAE ZP
5	4	GSM31027	WASHER, 5/16" LOCK, ZP
6	4	GSM33011	SCREW, 5/16-18 X 3/4"
7	2	GSM31009	WASHER 1/2 FLAT ZP
8	2	GSM33744	HRDW,SCRW,12mm-1.75x75mm,HHCS,ZINC,GRADE 8

#### INSTALLATION INSTRUCTIONS

1. REMOVE PASSENGER SIDE FRONT SEAT BOLTS.
2. PLACE SPACERS AND BASE OVER SEAT BRACKETS.
3. INSTALL SUPPLIED LONGER SEAT BOLTS AND WASHERS AND TIGHTEN TO VEHICLE MANUFACTURER'S TORQUE SPECIFICATION.
4. ATTACH LOWER OFFSET TO BASEPLATE WITH 5/16" BOLTS, LOCK WASHERS AND FLAT WASHERS ANGLE TOWARDS CENTER OF VEHICLE.
5. FOLLOW GENERAL INSTRUCTIONS FOR POLE AND UPPER MOUNT PARTS.

<b>HAVIS HAVIS, INC.</b>		75 JACKSONVILLE RD. WARMINSTER, PA. 18974 1-800-524-9900	
TITLE: 99-16 FORD F-250-750 HDM BASE			
<b>DO NOT SCALE DRAWING</b>			
SIZE <b>A</b>	DWG. NO. C-HDM-142-INST	REV 3-13	
WEIGHT (LB): 10.21	SCALE: 1:8	SHEET 1 OF 1	