



#### INSTALLATION INSTRUCTIONS

1. REMOVE PASSENGER SIDE FRONT SEAT BOLTS.
2. PLACE SUPPLIED SPACERS BETWEEN THE SEAT BRACKET AND HDM BASE.
3. INSERT SUPPLIED M10 BOLTS THROUGH 1/2" WASHER, BASE PLATE, SUPPLIED SPACER AND OEM SEAT. TIGHTEN TO VEHICLE MANUFACTURER'S TORQUE SPECIFICATION.
4. ATTACH FIRST LOWER OFFSET TO BASEPLATE WITH 5/16" BOLTS, LOCK WASHERS AND FLAT WASHERS, ANGLE TOWARDS CENTER OF VEHICLE.
5. ATTACH SECOND LOWER OFFSET TO FIRST LOWER OFFSET WITH 5/16 BOLTS, WASHERS AND NUTS, ANGLE TOWARDS REAR OF VEHICLE.
6. FOLLOW GENERAL INSTRUCTIONS FOR POLE AND UPPER MOUNT PARTS.

ITEM NO.	QTY.	PART NUMBER	DESCRIPTION
1	2	CM002400	BRACKET, MOUNT, 45° 3.5" LOWER OFFSET BASE W/SLOTS
2	2	10-003319	SPACER, 1"
3	1	10-005461	BRACKET, MOUNT, HDM, BASE, FORD EXPLORER, FUSION
4	1	C-HK-102	BASE OFFSET HK
	4	GSM31006	WASHER, 5/16" FLAT, SAE ZP
	4	GSM33011	SCREW, 5/16-18 X 3/4"
5	4	GSM30007	NUT 5/16-18 HEX ZP
6	8	GSM31006	WASHER, 5/16" FLAT, SAE ZP
7	2	GSM31009	WASHER 1/2 FLAT ZP
8	4	GSM31027	WASHER, 5/16" LOCK, ZP
9	4	GSM33012	SCREW 5/16-18 X 1 HHCS ZP
10	2	GSM33734	HRDW,SCRW,10mm-1.50x50mm,HHCS, ZP, GRD 8

<b>HAVIS</b>		<b>HAVIS, INC.</b>		75 JACKSONVILLE RD. WARMINSTER, PA. 18974 1-800-524-9900	
TITLE: 2013-18 FORD FUSION HDM BASE					
DO NOT SCALE DRAWING					
SIZE <b>A</b>	DWG. NO. C-HDM-163-INST				REV 9-17
WEIGHT (LB): 11.89		SCALE: 1:8		SHEET 1 OF 1	