



INSTALLATION INSTRUCTIONS

1. REMOVE PASSENGER SIDE FRONT SEAT BOLTS.
2. SLIDE BASE PLATE IN BETWEEN FLOOR AND SEAT BRACKETS.
3. REINSTALL OEM SEAT BOLTS AND TIGHTEN TO VEHICLE MANUFACTURER'S TORQUE SPECIFICATION.
4. ATTACH LOWER OFFSET TO BASEPLATE WITH 5/16" BOLTS, LOCK WASHERS AND FLAT WASHERS ANGLE TOWARDS CENTER OF VEHICLE.
5. FOLLOW GENERAL INSTRUCTIONS FOR POLE AND UPPER MOUNT PARTS.

ITEM NO.	QTY.	PART NUMBER	DESCRIPTION
1	1	10-007208	BRACKET, MAIN, BASE, F-150 2015
2	1	CM002531	BRACKET, MOUNT, 55 DEG. 5" LOWER OFFSET BASE W/ SLOTS
3	4	GSM31006	WASHER, 5/16" FLAT, SAE ZP
4	4	GSM31027	WASHER, 5/16" LOCK, ZP
5	4	GSM33011	SCREW, 5/16-18 X 3/4"

HAVIS HAVIS, INC.		<small>75 JACKSONVILLE RD. WARMINSTER, PA. 18974 1-800-524-9900</small>	
TITLE:		2015-18' F-150 HDM BASE	
DO NOT SCALE DRAWING			
SIZE A	DWG. NO. C-HDM-185-INST	REV 2-16	
WEIGHT (LB): 9.533	SCALE: 1:8	SHEET 1 OF 1	