

C-VS-1308-INUT INSTALLATION INSTRUCTIONS

1/4-20 X 1/2" CARRIAGE
BOLT GSM31999 & 1/4-
20 SERRATED NUTS
GSM30023, 12X

1/4-20 X 1/2" HHCS
GSM33300, 2X

1/4-20 SERRATED
NUT GSM30023, 2X

CM005693

CM004883

CM004828

CM004942

M6-1.0 X 20MM HHCS, GSM33711, 2X
1/4" WASHER GSM31005, 2X

CM004829

CM004941

1/4-20 X 3/4" HHCS GSM33001, 2X
1/4-20 WASHER GSM31005, 2X

1. REMOVE (UNSNAP) CENTER DASH SIDE TRIM PANELS TO ACCESS OEM FRONT TUNNEL PLATE HARDWARE.
2. REMOVE OEM TUNNEL PLATE. RETAIN OEM HARDWARE.
3. DISASSEMBLE FRONT MOUNTING BRACKET CM004883 FROM CONSOLE.
4. LOOSELY ATTACH CM004883 FRONT MOUNTING BRACKET, CM004828 MID DS MOUNTING BRACKET & CM004829 MID PS MOUNTING BRACKET TO OEM TUNNEL USING OEM HARDWARE.
5. LOOSELY ATTACH CM004941 TO CM004942 USING SUPPLIED HARDWARE.
6. LOOSELY ATTACH CM005693 SUPPORT BRACKET TO CM004883 USING SUPPLIED HARDWARE IN THE ORIENTATION SHOWN.
NOTE CM005693 WILL NOT WORK WITH A HAVIS ICS SYSTEM INSTALLED.
7. REPLACE CENTER DASH SIDE TRIM PANELS.
8. LOWER HAVIS CONSOLE OVER MOUNTING BRACKETS AND SLIDE INTO POSITION.
9. ATTACH CONSOLE HOUSING TO MOUNTING BRACKETS WITH 1/4-1/2" LG. CARRIAGE BOLTS AND SERRATED NUTS.
10. TIGHTEN ALL HARDWARE.
11. CONSOLE INCLUDES PROVISIONS FOR **OPTIONAL** OEM REAR CONDUIT. REMOVE SQUARE KNOCKOUT FROM END PANEL, PLACE CONSOLE OVER CONDUIT, ATTACH WITH SPACERS PROVIDED AND OEM REAR BRACKET SCREWS.

NOTE: 2017 INUT INCLUDES A NEW SENSOR ON THE FLOOR. FRONT BRACKET # CM004883 MANUFACTURED AFTER 11/1/16 INCLUDES STUDS AND NUTS FOR MOUNTING THE SENSOR. IF YOU HAVE AN OLDER CONSOLE, THE INSTALLER WILL NEED TO DRILL FLOOR AND PROVIDE HARDWARE FOR MOUNTING SENSOR.

HAVIS		HAVIS, INC.		75 JACKSONVILLE RD. WARMINSTER, PA. 18974 1-800-524-9900	
TITLE: C-VS-1308-INUT, INSTALLATION INSTRUCTIONS					
DO NOT SCALE DRAWING					
SIZE A	DWG. NO. C-VS-1308-INUT-INST			REV 10/18	
SCALE: 1:8			SHEET 1 OF 1		