

INSTALL INSTRUCTIONS C-VSW-2000-TAH-2

2015-2020 Chevy Tahoe Police Pursuit Vehicle (PPV)

Vehicle Specific Console (12.5" inches wide)

20" inches of Equipment mounting space

TOOLS REQUIRED:

Phillips Screw Driver	Standard Socket set	T-20 Torx Bit
Metric Socket set	Wire Cutters	Wire Crimping tool

INSTALLATION PARTS AND MOUNTING HARDWARE:

<u>QTY</u>	<u>DESCRIPTION</u>	<u>PART#</u>	
1	Main Console housing		
2	Floor brackets	CM006193	
1	Driver side trim panel	CM008217	
1	Passenger side trim panel	CM009195	
1	Top trim panel	CM006409	
1	Electrical accessory mounting plate	CM005915	
1	Rear end cap for hump bracket	CM006410	
2	12 volt socket with cap	CM216560	
1	Wire harness for 12 volt sockets	CMC-E2	
1	Accessory Pocket	CM005522	
1	Filler plate with pole knockout	CM005525	
1	Rocker Switch blank	C-SW-B	
2	1/2" Aluminum spacer (rear)	CM003200	}
2	3/4" Aluminum spacer (front)	CM003216	
1	7/8" Plug	CM86430	
8	#8 x 3/8 Torx head sheet metal screws	CM86508	
10	1/4" serrated nut	GSM30023	
2	8/32 Keps nut	GSM30027	
4	1/4" Flat washer	GSM31005	
4	7/16" Flat washer	GSM31011	
4	3/8" id x 1-5/8" od Fender washer	GSM31149	
8	1/4" x 3/4" Carriage bolt	GSM32000	
4	1/4" x 3/4" Hex bolt	GSM33001	
2	8/32 x 1/2" Phillips pan head machine screw	GSM33110	
4	3/8 x 1.75" Hex bolt (if floor mount location is not threaded)	GSM33303	
4	10mm x 45mm Hex bolt (if floor is already threaded)	GSM33733	

Notes: 1. This console was designed for the Police Pursuit Tahoe. However it can be installed into a Retail Tahoe or Suburban by removing the OEM center console. When the OEM console is removed, you must order the lower center trim panel from Chevy. Consoles will not fit properly without OEM lower center trim. Chevy part number for instrument panel lower center trim #22885554 (Color – Black)

2. OEM #22885554 was changed to #84565261 in 2019.

3. The C-VSW-2000-TAH-2 console provides mounting for the OEM Aux module, 12 volt and 110 volt sockets, but it does **NOT** have provisions for relocating the controls from the rear end of the OEM console.

ALWAYS!

* Read all Instructions before installing any Havis, Inc. products.

* Use Hardware included with install kit

**C-VSW-2000-TAH-2
(Assembly)**

Console includes Top accessory panel with:

- Two (2) 12 volt sockets CM216560 and power wires CMC-E2
- Cutout for OEM Aux module.
- Rectangle cutout for optional C-SW-X. rocker switch or C-USB-2.
- Blank cover for rectangle cutout C-SW-B
- 7/8" hole for additional optional 12 volt socket CM216560.
- 7/8" hole plug CM86430.

Top forward contoured trim panel
CM006409

Passenger side trim panel
CM009195

Electrical Accessory mounting plate
Between trim panels
CM005915
(Not shown)

Filler Plate with pole knockout
CM005525

Driver side trim panel
CM008217

Note:
Newer style plastic speaker grills snap into the large holes in the side of console. Grill mount hardware is only required if attaching speaker on the inside of grill. Hardware not provided.
Recommended Hardware: (4x) #8 Keps nuts, (4x) 8-32 x 3/4" screws

CM006193
Floor bracket
(one each side)

End panel to cover Hump bracket assembly
CM006410

IMPORTANT NOTES:

Install CM006193 floor brackets to existing OEM mount points as follows.
Between bracket and hump, use 1/2" spacers at rear and 3/4" spacers at front.

RE: Police Pursuit Vehicle without center seat or OEM console
Use 3/8" x 1.75" self threading bolts and 3/8" flat washers and spacers
RE: Retail Tahoe or PPV (code A95) with OEM center console or PPV with center seat
Remove console or seat and use 10mm x 45mm bolts and 3/8" flat washers and spacers

Photos currently do not show the new speaker vents in the side trim panels. It is up to the installer to determine if a speaker or other device can be mounted behind these vents for their specific application.



View of 2015 Tahoe transmission hump between front seats



Install CM006193 hump brackets to existing OEM mount points.
 Use 10mm x 45mm bolts and 3/8" flat washers (Retail Tahoe)
 Or 3/8" x 1.75" self threading bolts and washers for (Police Package)
 Between bracket and hump, use 1/2" spacers at rear and 3/4" spacers at front.



Place main console housing on floor brackets and loosely attach with eight (8) 1/4 x 3/4 carriage bolts and serrated nuts.
Note: Bolts come up through bottom. (Nuts on top)



Loosely attach top trim panel (CM006409) to the underside of the console housing with 8/32 x 1/2" machine screws and Keps nuts.



Install the OEM Aux module into the top front console panel.
Note: The OEM harness is long enough for relocating aux module.



Loosely attach the electrical accessory mounting plate (CM005915) to the console "U" bracket with 1/4" x 3/4" Hex bolts and washers. (forward mount tabs face down)



Attach driver side trim panel to console with four (4) #8 x 3/8 Torx head sheet metal screws.



Attach passenger side trim panel to console with four (4) #8 x 3/8 Torx head sheet metal screws.

Remove knockout for 120 volt socket if you plan to relocate OEM 120 v socket to this location.



Install 12 volt and OEM 120 volt sockets in side panel if desired. **Note:** This photo shows the OEM 120 volt socket mounted in the side trim. OEM wire ties and tape may need to be cut in order to have enough wire to extend to this location. Splicing four (4) wire extensions may also be required. **Wire and eight (8) butt connectors for extensions must be supplied by the installer.**



Install 7/8 plug and small cover plate in side panel if 12 volt is not used.



Before closing top of console, position housing and trim panels to fit the dash and tighten all mounting hardware.



Mount arm rest, storage pocket, cup holder and other plates as desired.



View of C-HDM-204 mounted to the outside of console housing.



View of C-HDM-204 mounted to the outside of console housing with C-MD-302, PKG-KB-106 and DS-GTC-201.



View of C-HDM-204 mounted to the inside of console housing.



View of C-HDM-204 mounted to the outside of console housing with C-MD-302, PKG-KB-106 and DS-GTC-201.



Double check all mounting and equipment functions.



Installation complete