



TOOL LIST:

- 1. 2MM ALLEN WRENCH (PROVIDED)

ASSEMBLY STEPS:

1. INSTALL THE **M3 X 8MM LONG BUTTON HEAD CAP SCREW** TO THE UNDERSIDE OF THE **CREDIT CARD MACHINE**. AS SHOWN IN **DETAIL B**
2. ASSEMBLE THE **CREDIT CARD MACHINE** TO THE **10° WEDGE BRACKET** BY SLIDING IT ONTO THE **KEYHOLE STANDOFFS** AS SHOWN.
3. THREAD THE **THUMB SCREW** INTO THE **10° WEDGE STAND** TO SECURE THE **CREDIT CARD MACHINE** AS SHOWN.

DWG. NO. 367-2439	REV. D	TITLE 10 DEG WEDGE VERIFONE MX915/MX925/M424/M425	HAVIS SHEET 1 OF 1
DRAWN A. MCLAUGHLIN	DATE 3/19/2012		

REVISIONS				
REV	DESCRIPTION	DATE	BY	CHK'D
D		12/04/12	JEB	JEB

CUSTOMER INSTRUCTIONS