

ASSEMBLY STEPS: (CONTINUED FROM SHEET X)

- 1. ATTACH THE **SCANNER BRACKET** TO THE **EXISTING FLEXIPOLE STAND**USING **2X M3 X 8MM LONG PHILLIPS SCREWS** AS SHOWN.
- 2. ATTACH THE **SCANNER** TO THE **SCANNER BRACKET** USING **2X M3 X 6MM LONG PHILLIPS SCREWS** AS SHOWN.

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF HAVIS AND REPRODUCTION IN PART OR IN WHOLE WITHOUT THE WRITTEN PERMISSION OF HAVIS IS PROHIBITED.

		В			03/18/22	JVT	ARS	
_		REV.	DESCRIPTION			BY	CHK'D	
	DIMS. AND TOLERANCES PER ASME Y14.5 - 1994	DRAWN J. TERVEER	NJ. TERVEER					
	UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES	DATE 06/21/20)21					
	TOLERANCES ARE:	CHECKED						
	FRACTIONAL ± 1/32	DATE	TITLE	CUSTOMER				
	2 PLC. DEC. ± .03	DO NOT SCALE DRAWI			ER MOUNT,			
	3 PLC. DEC. ± .010	MATERIAL	─ FC	FOR FLEXIPOLE C		TE STA	'ND	
	01LC. DLC. 1 .010	SEE BOM	SIZE	DWG. NO. 367	7-5686	RE	∨. B	
١	ANGULAR ± 0°30'	SEE NOT	ES B			SH	HEET 1 OF 1	