



TOOL LIST:

1. #2 PHILLIPS SCREW OR DRILL DRIVER

ASSEMBLY STEPS:

- 1. ATTACH CUSTOMER'S EXISTING HP ENGAGE MONITOR WITH GENESIS BASE TO STABILITY PLATE MOUNT USING 3X #6-32 X .31 LONG PHILLIPS SCREWS.
- A 2. SNAP **GENESIS STAND COVERS** IN PLACE AS SHOWN.
 - 3. ATTACH THE ASSEMBLED **STABILITY PLATE MOUNT** TO THE **HP ENGAGE ONE** FANLESS HUB BASE (CUSTOMER SUPPLIED) AS SHOWN, USING 4X CAPTIVE **M3 BOLTS** INSTALLED IN THE CONNECTIVITY BASE.
 - 4. SECURE CABLES TO UNDERSIDE CABLE TIE DOWNS USING BLACK CABLE TIES.

2