

DETAIL A


TOOLS LIST:

1. #2 PHILLIPS SCREW DRIVER

ASSEMBLY STEPS:

1. REMOVE **CREDIT CARD MACHINE** FROM **EXISTING CENTER HOLE SWIVEL STAND** BY REMOVING **EXISTING MACHINE THUMB SCREW** (DISCARD) AND LIFT **CREDIT CARD MACHINE** OFF OF **KEYHOLE STANDOFFS** AS SHOWN.
2. ATTACH **WIRE HARNESS** USING PROVIDED **#8-32 X .25" LONG PHILLIPS SCREW** AS SHOWN.
3. ATTACH **FIXED REAR LOCKING BRACKET** TO **EXISTING CENTER HOLE SWIVEL STAND** BY USING **2X #8-32 X .38" LONG PHILLIPS SCREWS** AS SHOWN. MAKE SURE TO INSTALL IN UPPER HOLES (MX925) AS INDICATED ON **MOUNTING PLATE**.
4. REINSTALL **CREDIT CARD MACHINE** ONTO **EXISTING CENTER HOLE SWIVEL STAND** BY SLIDING IT BACK ONTO **KEYHOLE STANDOFFS**.
5. FEED **MACHINE CABLE** THROUGH **CABLE CLIP** AND **FIXED REAR LOCKING BRACKET**
6. MOVE **HINGED REAR LOCKING BRACKET** INTO PLACE AND LOCK AS SHOWN IN **DETAIL A**.

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF HAVIS AND REPRODUCTION IN PART OR IN WHOLE WITHOUT THE WRITTEN PERMISSION OF HAVIS IS PROHIBITED.

DIMS. AND TOLERANCES PER ASME Y14.5 - 1994 UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE:		DRAWN W. CLAIRE		11/03/22	WJC	WJC
FRACTIONAL ± 1/32		DATE	11/3/2022	DATE	BY	CHK'D
2 PLC. DEC. ± .03		CHECKED		 TITLE CUSTOMER INSTRUCTIONS, REAR LOCKING, ADD-ON KIT, VERIFONE M424		
3 PLC. DEC. ± .010		DATE				
ANGULAR ± 0°30'		DO NOT SCALE DRAWING				
FINISH -		MATERIAL	-	SIZE	DWG. NO.	367-6077
		REV.	A	SHEET 1 OF 1		