



**ASSEMBLY STEPS:**

1. ATTACH **BACKPLATE** TO **PAX A80** BY SLIDING **2X TABS** INTO BACK OF **PAX A80**.
  2. SLIDE **RETAINING CLIP** TOWARDS THE FRONT OF THE DEVICE TO HOLD **PAX A80** TO **BACKPLATE**.
- NOTE: **LISTEN FOR AUDIBLE CLICK WHEN FULLY ENGAGED**
3. ATTACH **PAX A80 INSTALLED TO BACKPLATE** TO THE **EXISTING TAILWIND STAND** AS SHOWN.

DWG. NO. CST00177	REV. A	TITLE PAX A80 BACKPLATE
DRAWN A. NORLING	DATE 12/31/2021	

REV.	DESCRIPTION	DATE	BY
A	-	12/31/21	AN

SHEET 1 OF 1

REVISIONS			
REV.	DESCRIPTION	DATE	BY
A	-	12/31/21	AN

CUSTOMER INSTRUCTIONS