


**TOOL LIST:**

1. #2 PHILLIPS SCREW OR DRILL DRIVER

**ASSEMBLY STEPS:**

1. CONNECT **VERIFONE P630** TO **BACKPLATE** AND SECURE USING **2X M3 X 6MM LONG PHILLIPS SCREWS**.
2. ATTACH THE **VERIFONE P630/BACKPLATE** TO THE **TAILWIND FLEXIPOLE PLUS STAND** BY SNAPPING IT INTO PLACE AS SHOWN.
3. ROUTE THE **DEVICE CABLE** AS DESIRED.

# CUSTOMER INSTRUCTIONS

REV.	DESCRIPTION	DATE	BY	CHK'D
A	INITIAL RELEASE	04/14/21	AN	AN
DRAWN	A. NORLING			
DATE	4/14/2021			
CUSTOMER APPROVAL (SIGNATURE REQUIRED):	 14451 Ewing Ave - Burnsville, MN 55306 952-767-1005			
TITLE				
BACKPLATE FOR VERIFONE P630				
ALL DIMENSIONS ARE IN INCHES	SIZE	DWG. NO.	REV. A	
DATE	B	CST00189	SHEET 1 OF 1	