



**TOOL LIST:**

1. #2 PHILLIPS SCREW OR DRILL DRIVER

**ASSEMBLY STEPS:**

1. CONNECT **INGENICO MOVE 5000** TO **BACKPLATE** AND SNAP INTO PLACE.
2. ATTACH **CABLE COVER** TO THE **BACKPLATE** USING **4-40 X .25 LONG ATTACHMENT SCREW** AS SHOWN.
3. ATTACH THE **INGENICO MOVE 5000** TO THE **TAILWIND FLEXIPOLE PLUS STAND** BY SNAPPING IT INTO PLACE AS SHOWN.

DWG. NO.  
CST00200

REV.  
C

TITLE

BACKPLATE  
FOR INGENICO MOVE 5000



SHEET 1 OF 1

CUSTOMER INSTRUCTIONS