



ASSEMBLY STEPS FOR TABLET:

1. USING PROVIDED ALCOHOL WIPE BOTH **BACKPLATE** AND BACK SIDE OF **TABLET**.
2. REMOVE PAPER BACKER FROM ONE SIDE OF **ADHESIVE PAD** AND ATTACH TO **BACKPLATE**.
3. REMOVE PAPER BACKER FROM **ADHESIVE PAD** AND SECURE IT TO **TABLET** AS SHOWN.
4. ATTACH **BACKPLATE** TO **MM-1000 MOUNTING ARM**.

TOOLS

1. #2 PHILLIPS SCREWDRIVER

ASSEMBLY STEPS FOR MONITOR:

1. SECURE **MONITOR** TO **BACKPLATE** USING **4X M4 X 8MM POZI SCREWS**.
2. ATTACH **BACKPLATE** TO **MM-1000 MOUNTING ARM**.

DWG. NO. CST00205	REV. A	TITLE
DRAWN A. NORLING	DATE 11/2/2021	

TITLE	
UNIVERSAL TABLET/MONITOR MOUNT, MM-1000 BACKPLATE W/ ADHESIVE PAD AND VESA PATTERN ATTACHMENT SCREWS	


 SHEET 1 OF 1

REVISIONS				
REV	DESCRIPTION	DATE	BY	CHK'D
A		11/02/21	AN	AN

CUSTOMER INSTRUCTIONS