



Tablet Setup

- Using 11/32 wrench, loosen locknuts (6x)
- Verify release flange is in locked position (shown above)
- Insert tablet and adjust horizontal/vertical extensions as tightly as possible to the tablet edges
- Using 11/32 wrench, tighten all locknuts (6x)

Tablet Removal

- Pull plunger outward
- Slide release flange upward
- Remove tablet from mount

UT-5001-INST REV A

Installation

- ** If using MD-501 mount **
Insert nut plate onto neck of MD-501 as shown above
- Insert (4) M4 phillips flat head screws through tablet mount and thread into nut plate

Tablet Installation - Part 1

- Verify release flange is in unlocked position (shown above)
- Place tablet into mount inserting bottom edge first

Tablet Installation - Part 2

- Slide release flange downward and verify plunger clicks into its locked position