



1. Remove insert from TC51 Sharecradle

- * The rugged boot insert installed in the TC51 Sharecradle **MUST** be removed for the ENS adapter to fit.
- Squeeze both corners of rugged boot insert inward as shown.
- Lift insert out and save with packaging.



1



2. Install adapter onto charger

- Place the adapter over the charger in the correct orientation (as shown) and slide down over the charger into position.
- Firmly push adapter down on both sides until two audible clicks are heard.
- Adapter is now locked into position.


2



3. Insert mobile device for charging


- Assemble mobile device (instructions for mobile device assembly included with ENS case P/N 367-4190).
- Place mobile device over Sharecradle in the correct orientation (as shown).
- Gently drop mobile device into charger.
- Visually verify that both devices are charging.

3



4. Remove mobile device from charger


- Grip mobile device and pull up to remove from charging station.



4

5. Release adapter from charger


- Squeeze inward on both release buttons to release adapter from charger.



5

6. Remove adapter from charger

- While squeezing release buttons, pull up on adapter and off of charger.



6