
INSTALLATION INSTRUCTIONS

5



6

TOOLS LIST:

8

8

7

. #2 PHILLIPS SCREW DRIVER

ASSEMBLY STEPS:

1. REMOVE CREDIT CARD MACHINE FROM EXISTING CENTER HOLE SWIVEL STAND BY REMOVING **EXISTING MACHINE THUMB SCREW** (DISCARD) AND LIFT **CREDIT CARD** MACHINE OFF OF KEYHOLE STANDOFFS AS SHOWN.

2. ATTACH WIRE HARNESS USING PROVIDED #8-32 X .25" LONG PHILLIPS SCREW AS SHOWN. (INTO HOLE THE THUMB SCREW WAS IN)

3. ATTACH FIXED REAR LOCKING BRACKET TO EXISTING CENTER HOLE SWIVEL STAND BY USING 2X #8-32 X .38" LONG PHILLIPS SCREWS AS SHOWN. MAKE SURE TO INSTALL IN UPPER HOLES (MX925) AS INDICATED ON MOUNTING PLATE.

- 4. REINSTALL CREDIT CARD MACHINE ONTO EXISTING CENTER HOLE SWIVEL STAND BY SLIDING IT BACK ONTO KEYHOLE STANDOFFS.
- 5. FEED MACHINE CABLE THROUGH CABLE CLIP AND FIXED REAR LOCKING BRACKET AS SHOWN IN **DETAIL B**.

6

6. MOVE HINGED REAR LOCKING BRACKET INTO PLACE AND LOCK AS SHOWN IN **DETAIL A**.


7

4

5


HINGED REAR LOCKING BRACKET

3



1

2



(UNLOCKED)

(LOCKED)

1

D

С

DETAIL A

	В				09/22/21	TAS	TAS	
	REV.	DESCRIPTION			DATE	BY	CHK'D	
DIMS. AND TOLERANCES PER ASME Y14.5 - 1994	DRAWN	t. strand	Havis, Inc.					
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES	DATE	4/8/2019	H	ĄVIS	14451 Ewing A	14451 Ewing Ave. Burnsville, MN 55306		
TOLERANCES ARE:	TOLERANCES ARE: CHECKED							
FRACTIONAL ± 1/32	DATE		TITLE CUSTOMER INSTRUCTIONS, LOW CONTOUR 8°-90°, WITH REAR LOCKING PLATE, CENTER HOLE SWIVEL STAND,					
2 PLC. DEC. ± .03	DO NOT SCALE DRAWING							
3 PLC. DEC. ± .010	MATERIAL	-	ANTI SKIMMING FEATURE, EMV CARD CLEARANCE VERIFONE M440					
ANGULAR ± 0°30'	FINISH –		SIZE	DWG. NO.	367-5123	RE	∨. B	
			C		307-3123	S	HEET 1 OF	

THE INFORMATION CONTAINED IN THE DRAWING IS THE SOLE PROPERTY OF HAVIS, INC. AND REPRODUCTION IN PART OR IN WHOLE WITHOUT THE WRITTEN PERMISSION OF HAVIS, INC. IS PROHIBITED.

2