


INSTALLATION INSTRUCTIONS:

- 1. Review the parts list and ensure you have all parts and tools required for assembly.
- 2. If converting another UT-1000 series product, first remove the existing side lugs and rear fences.
- 3. Loosely assemble the new kit to the base tray as shown in the exploded view.
- 4. Adjust and tighten the new kit according to the configuration instructions in the UT-1000 Series owner’s manual or go to www.havis.com for more information.

NOTE: Retain all unused hardware for possible future re-use.



DRAWING NUMBER:
UT-1003-KIT_INST_6-19

WARNING: ALL HAVIS INC. PRODUCTS ARE DESIGNED WITH SAFETY OF USE AND INSTALLATION IN MIND. HOWEVER, IT IS THE SOLE RESPONSIBILITY OF THE OWNER/OPERATOR OF A VEHICLE USING HAVIS INC. MOUNTING AND DOCKING EQUIPMENT, TO INSURE THAT THE EQUIPMENT IS INSTALLED SO THAT IT WILL NOT INTERFERE WITH VEHICLE OPERATION, INTERFERE WITH SAFETY DEVICES, OBSTRUCT VIEW OF DRIVING CONDITIONS, OR IN ANY WAY DEGRADE OCCUPANT SAFETY. IMPROPER INSTALLATION CAN CAUSE SERIOUS INJURY IN THE EVENT OF AN ACCIDENT. INSTALLATION SHOULD ONLY BE PERFORMED BY QUALIFIED PROFESSIONALS. COMPUTERS AND MOTION DEVICES MUST BE MOVED TO AND STOWED/SECURED IN THEIR SAFE DRIVING POSITIONS BEFORE OPERATING VEHICLE.

PRODUCT DESCRIPTION

REPLACEMENT
PARTS KIT, UT-1003


UT-1003-KIT HARDWARE CONTENTS

REPLACEMENT PARTS

ITEM NO.	DESCRIPTION	HAVIS PART NUMBER	QTY.
1	BRACKET, HOLD DOWN LUG, TALL, UT-100 SERIES	UT-0111-SM	4
2	FENCE, REAR, UT-200 SERIES	UT-0199-ML	2
3	SCREW, BUTTON HEAD, PIN-IN-TORX, #10-32 X 0.5"	GSM33327	7
4	WASHER, BELLEVILLE, SERRATED, #10	HW-SW-1262/GSM31089	5
5	CAP - 0.45" X 0.5", 0.04" THK	HW-CA-0001/GSM41120	4
6	INSTALLATION INSTRUCTIONS, UT-1003-KIT	UT-1003-KIT_INST	1

TOOLS

7	L-KEY TAMPER-RESISTANT, T25, 2-13/32" L	HW-AW-0006/GSM50261	1
---	---	---------------------	---



PRODUCT I.D.	DATE
UT-1003-KIT	06-07-19

PRODUCT NAME
UT-1003 KIT

HAVIS 1-800-524-9900 WWW.HAVIS.COM	WEIGHT: (LBS)
	REV. DATE 6-19