


INSTALL INSTRUCTIONS C-VS-2400-CHGR-2

24" Vehicle Specific Console for 2011-12 Dodge Charger (Police Package)

TOOLS NEEDED:

- | | | |
|--------------------------------|--------------|--------------------|
| Phillips Screw Driver | Wire Cutters | Wire Crimping tool |
| Socket set (Standard & Metric) | 7/16 wrench | T-20 Torx Bit |

<u>QTY</u>	<u>DESCRIPTION</u>	<u>PART #</u>
1	Main Console Housing	CM004341
1	Floor Mount Bracket (included with CM004341)	CM003956
1	Front / Center End Panel (included with CM004341)	CM004377
1	Sensor Cover	CM001638
1	Driver Side Trim Panel	CM004378
1	Passenger Side Trim Panel	CM004379
1	Hardware kit (parts in kit listed below)	C-HK-170
6	#8 x 1/4" Phillips Flat head screw	GSM33178
3	1/4" x 3/4" Self Threading screw	GSM33060-1
2	1/4" x 1" Fender washer	GSM31014
2	6mm Hex nut	GSM30201
4	1" x 1" Velcro Hook & Loop	GSM20080
1	O-Ring	KRM98017
1	7/8 plug	CM86430
2	Lighter Socket Kit (parts in kit listed below)	C-HK-181
2	12 volt socket (one per kit)	CM216560
4	1.375" OD x .875" ID washer (two per kit)	GSM31147
4	1/4 Spade terminal (two per kit)	GSM20220



NOTE: If your vehicle has the optional carpet interior, there will be a small hole in the carpet not covered by the console housing at the rear. If desired, an optional cover plate part number - CM001642 is available. Cover plate not shown.

Always!

- Read all instructions before installing any Havis, Inc. products.
- Use Hardware provided with install kit.



O.E.M. console prior to C-VS-2400-CHGR-2 installation.



Remove forward O.E.M console plastic cover and remove two (2) nuts from front floor bracket. Nuts to be reused. (10mm)



Remove bolts that hold underside of extrusion to rear floor bracket. (7/16 wrench)
Remove rear floor bracket bolts and center console bolt. (10mm)



Remove O.E.M. plastic center console



Remove Ignition proximity sensor / antenna from rear underside of O.E.M. console. (Phillips Screwdriver)
**** SEE NOTE BELOW ****



Remove sensor and 12 volt socket wire harness assembly from under side of O.E.M. console.
Pop out "AUX" socket from center of O.E.M console.



Plug O.E.M. wire harness back onto original connectors.



Attach self adhesive Velcro pads onto bottom of Ignition proximity sensor /antenna and to transmission hump.
Note: Newer cars may include a bracket with this sensor already relocated. If so, Velcro will not be needed.




Attach Sensor to transmission hump.

NOTE: 2012 and newer cars include an O.E.M. bracket with this sensor already relocated. Velcro mounting will not be.



Carefully remove O.E.M. 12 volt sockets and "AUX" socket from OEM plastic panel. Small flat screwdriver can be used to push sockets out.



Place # KRM98017 Rubber "O" Ring onto AUX socket assembly. Push ring all the way on. This allows for a tight fit when installed.



Firmly push in the O.E.M 12 volt sockets and Auxiliary socket assembly into center End Panel Cutout. "AUX" lettering goes to passenger side.



Two (2) aftermarket 12 volt socket kits #C-HK-184 are included with this Charger console. The installer has the option to use either the OEM or Aftermarket 12 volt sockets. (C-HK-181 socket shown installed)



Carefully place console assembly between seats and onto front O.E.M. floor studs. Loosely attach previously removed nuts onto floor studs. (10mm)



Use 1/4 x 3/4 self threading screws (included in hardware kit) to loosely attach rear of console to existing floor inserts. Inserts located under rubber mat as shown. (7/16 socket)



Plug 12 volt sockets and "AUX" USB connectors back together.



Attach passenger side trim panel on with # 8 x 1/4 Flat Head Screws. (included with hardware kit) (Phillips Screwdriver) After console housing is firmly mounted, remove panel as needed to run wires



Attach driver side trim panel on with # 8 x 1/4 Flat Head Screws. (included with hardware kit) (Phillips Screwdriver) After console housing is firmly mounted, remove panel as needed to run wires



Push Console assembly forward and tighten all floor mount bracket hardware. Run wiring as needed.



A Cover is provided to guard the O.E.M. Sensor on transmission hump. Attach to existing stud and 6mm nut and washer provided.



Install Control heads and accessories. If necessary, remove side trim panel for easier computer mount bracket access.



Completed console installation with Laptop / Docking Station (example 1)



Completed console installation with Self Contained Radio and accessories. (example 2)



Completed console installation (example 3)



NOTE:
Photo of Kit # C-HK-181 (shown) these parts will be needed if you choose not to use the larger OEM socket.