

TOOLS REQUIRED:

1. POWER DRILL
2. 5/32" DRILL BIT
3. EYE SAFETY GOGGLES
4. PHILLIPS SCREW DRIVER

USE LONGER
SCREWS ON
EACH SIDE




FIG. 1

HARDWARE:

QTY	DESCRIPTION	PART #
1	DS WINDOW BAR	WBI-F18-1
6	#10 X 3/4" LG. SHEETMETAL SCREW, BLK	GSM33195
8	#10 X 1/2" LG. SHEETMETAL SCREW, BLK	GSM33214

INSTALLATION INSTRUCTIONS:

1. OPEN DOOR AND POSITION THE GUARD TO CONTOUR AROUND DOOR PANEL TO FIT EVENLY AROUND DOOR WINDOW.
2. WITH GUARD POSITIONED, MARK THE DOOR FRAME USING GUARD MOUNTING HOLES AS A GUIDE.
3. REMOVE WINDOW GUARD, AND DRILL THE MARKED HOLES USING # 5/32 DRILL BIT.
4. RE-POSITION WINDOW GUARD AND ATTACH USING SUPPLIED HARDWARE.
5. MAKE SURE TO USE LONGER SCREWS AT 3 LOWER MOUNTING HOLES (FIG. 1) ON EACH SIDE.

HAVIS HAVIS, INC.		75 JACKSONVILLE RD. WARMINSTER, PA. 18974 1-800-524-9900
TITLE: FORD INUT, DS, REAR WINDOW BAR INSTALLATION INSTRUCTIONS		
DO NOT SCALE DRAWING		
SIZE A	DWG. NO. WBI-F18-1-INST	REV 3/14
WEIGHT (LB): 9.61	SCALE: 1:16	SHEET 1 OF 1