






INSTALLATION INSTRUCTIONS



STEPS 1-2




BARCODE LOCATION




FRONT VIEW OF MONITOR MOUNTING BRACKET

- TOOLS LIST:**
1. #2 PHILLIPS SCREW OR DRILL DRIVER
 2. 3/16" HEX WRENCH
 3. 9/64" HEX WRENCH

- ASSEMBLY STEPS:**
1. SLIDE THE **INNER CLAMP** ONTO THE **POLE** AND HOLD AT THE DESIRED HEIGHT.
 2. TIGHTEN **2X #8-32 X .750 LONG SOCKET SCREWS** AS SHOWN. ENSURE THE **INNER CLAMP** IS INSTALLED WITH THE **STOP TAB** FACING FRONT AS SHOWN IN **DETAIL A**.
 3. SLIDE THE **ROTATING MONITOR PIVOT ASSEMBLY** ONTO THE **INNER CLAMP** AND TIGHTEN **2X 1/4-20 X .875 LONG SOCKET SCREWS** AS SHOWN. **DO NOT OVERTIGHTEN**
 4. ASSEMBLE THE **UPPER 2X M4 X 10MM LONG PHILLIPS SCREWS** INTO TOP HOLES OF **MONITOR** LEAVING 1/8" OF SPACE BETWEEN THE BACK OF THE **MONITOR** AND THE SCREW HEAD.
 5. PLACE THE **MONITOR** ONTO **MONITOR BRACKET** USING THE **VESA 100MM SLOT** OR **VESA 75MM KEYHOLE** PATTERN. SEE: **DETAIL B**
 6. INSTALL THE **LOWER 2X M4 X 10MM LONG PHILLIPS SCREWS** AND TIGHTEN THE **UPPER 2X M4 X 10MM LONG PHILLIPS SCREWS**.
 7. **OPTIONAL:** ATTACH THE **MONITOR CABLE** TO **BRIDGE LANCE** WITH **CABLE TIE** AS SHOWN IN **DETAIL C**.
 8. SCAN QR CODE ON LABEL OR REFERENCE THE FOLLOWING LINK FOR STEPS ON ADJUSTING THE TENSION OF THE MONITOR TILTING FEATURE: <https://youtu.be/jrPS0C5gSrE>



DETAIL C



STEPS 3-6

REV.	DESCRIPTION	DATE	BY	CHK'D
A		09/23/15	JEB	SY
REV.		DATE	BY	CHK'D
1	J. BROWN	9/23/2015		
HAVIS				
TITLE: TECHTOWER, CUSTOMER INSTRUCTIONS, MONITOR PIVOT, SINGLE (UP/DOWN) AND ROTATING FOR ONE MONITOR, ROTATING CLAMP INCLUDED				
DRAWN		DATE		
CHECKED		DATE		
DO NOT SCALE DRAWING				
MATERIAL N/A				
FINISH N/A				
SIZE C		DWG. NO. 367-4008-15		REV. A
				SHEET 1 OF 1

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF HAVIS AND REPRODUCTION IN PART OR IN WHOLE WITHOUT THE WRITTEN PERMISSION OF HAVIS IS PROHIBITED.