


MOUNTING OPTION #1




STEP 1

TOOL LIST:


- #2 PHILLIPS SCREW OR DRILL DRIVER
- 2MM ALLEN WRENCH (PROVIDED)

ASSEMBLY STEPS:

- ROTATE THE **SWIVEL BASE** LEFT OR RIGHT TO THE STOP POINT AND THEN COMPARE IT TO THE ILLUSTRATIONS ABOVE TO DETERMINE WHICH WAY YOU WANT IT TO ROTATE.
- ASSEMBLE THE **SWIVEL BASE** TO THE **COUNTER** BY USING **3X #10 X 1.00 PHILLIPS FLAT HEAD WOOD SCREWS** AS SHOWN **MAKING SURE IT IS IN THE CORRECT ORIENTATION BEFORE YOU SCREW IT TO THE COUNTER.**
- INSTALL THE **M3 X 8MM BUTTON HEAD CAP SCREW** TO THE UNDERSIDE OF THE **CREDIT CARD MACHINE** AS SHOWN IN **DETAIL A**
- ASSEMBLE THE **CREDIT CARD MACHINE** TO THE **MOUNTING PLATE** BY SLIDING IT ONTO THE **KEYHOLE STANDOFFS** AS SHOWN.
- THREAD THE **THUMB SCREW** INTO THE **MOUNTING PLATE** TO SECURE THE **CREDIT CARD MACHINE** AS SHOWN.



MOUNTING OPTION #2




STEP 2

TOOL LIST:

- #2 PHILLIPS SCREW DRIVER

ASSEMBLY STEPS:

- ASSEMBLE THE **COVER** TO THE **SWIVEL BASE** USING A **#6-32 SCREW** AS SHOWN.
- REPEAT ON OTHER SIDE



REV.	DESCRIPTION	DATE	BY	CHK'D
A		10/20/17	TAS	AZM
REV.	T. STRAND	DATE	10/20/2017	
CHECKED		DATE		
DIMS AND TOLERANCES PER ASME Y14.5 - 1994		<div style="text-align: center;"> <p>CUSTOMER INSTRUCTIONS, TELESCOPING STAND, CENTER HOLE SWIVEL, VERIFONE M400</p> </div>		
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE:				
FRACTIONAL	± 1/32			
2 PLC. DEC.	± .03			
3 PLC. DEC.	± .010			
ANGULAR	± 0°30'	FINISH		
SIZE	C	DWG. NO.	367-4633	REV. A
				SHEET 1 OF 1

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF HAVIS AND REPRODUCTION IN PART OR IN WHOLE WITHOUT THE WRITTEN PERMISSION OF HAVIS IS PROHIBITED.