




GENESIS INSTALLATION INSTRUCTIONS

DETAIL A



TOOL LIST:

1. #2 PHILLIPS SCREW OR DRILL DRIVER
2. 3/32 DRILL BIT WITH DRIVER
3. **OPTIONAL** 1 1/2" (1.50") SPADE BIT

ASSEMBLY STEPS:

1. USING **SWIVEL BASE** AS A TEMPLATE, MARK AND DRILL 3X 3/32 HOLES FOR USE WITH **3X #12 X 1.00 PHILLIPS WOOD SCREWS**.
2. (OPTIONAL) DRILL A 1 1/2" (1.50") THROUGH HOLE INTO YOUR **COUNTER**. FOR CABLE PASS THROUGH.
3. ATTACH **SWIVEL BASE** TO **COUNTER** USING **3X #12 X 1.00 PHILLIPS WOOD SCREWS** AS SHOWN IN **DETAIL A**. ENSURE CORRECT ORIENTATION BEFORE INSTALLING.
4. INSTALL THE **2X MONITORS** ONTO THE **2X MONITOR BRACKET** USING **8X M4 X 10MM LONG PHILLIPS SCREWS**.
5. ATTACH THE **2X MONITOR CABLES** TO THE **ZIP TIE LOCATIONS** USING PROVIDED ZIP TIES.
6. TO ADJUST THE SWIVEL TENSION, TIGHTEN THE **SWIVEL TENSION ADJUSTMENT SCREW** TO INCREASE TENSION OR LOOSEN **SWIVEL TENSION ADJUSTMENT SCREW** TO DECREASE TENSION.
7. TO ADJUST THE TILT TENSION, TIGHTEN THE **TILT TENSION ADJUSTMENT SCREWS** TO INCREASE TENSION OR LOOSEN **TILT TENSION ADJUSTMENT SCREWS** TO DECREASE TENSION.
8. ATTACH THE **SWIVEL BASE COVERS** TO THE **SWIVEL BASE** AS SHOWN IN **DETAIL A**.

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF HAVIS AND REPRODUCTION IN PART OR IN WHOLE WITHOUT THE WRITTEN PERMISSION OF HAVIS IS PROHIBITED.

A		02/14/22	SY	
REV.	DESCRIPTION	DATE	BY	CHK'D
	S. YANG	2/14/2022		
DIMS. AND TOLERANCES PER ASME Y14.5 - 1994 UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE:		<p>DISPLAY MOUNT, DUAL VESA, STANDARD DUTY</p>		
FRACTIONAL	± 1/32			
2 PLC. DEC.	± .03			
3 PLC. DEC.	± .010			
ANGULAR	± 0°30'			
DATE	DO NOT SCALE DRAWING	TITLE		
CHECKED	MATERIAL	SIZE	DWG. NO.	REV.
		C	DM-10-201	A
	FINISH	SHEET 1 OF 1		