


TOOLS LIST:

- 1. 5/32 TAMPER RESISTANT HEX WRENCH (ENS P/N 367-1046)
OR 5/32 TAMPER RESISTANT HEX BIT (ENS P/N 367-1102) WITH
SOCKET DRIVER. ENS PARTS EACH ORDERED SEPARATELY.
- 2. #2 PHILLIPS SCREW DRIVER

ASSEMBLY STEPS:

- 1. USING THE **SWIVEL BASE STAND** AS A TEMPLATE, ROTATE LEFT/RIGHT
TO STOP POINTS TO DETERMINE DIRECTION OF SWIVEL BEFORE MOUNTING
- 2. MARK MOUNTING LOCATION ON **COUNTER**
- 3. DRILL 9/64 HOLES IN MARKED LOCATION ON **COUNTER**
- 4. ASSEMBLE THE **SWIVEL BASE** TO THE **COUNTER** BY USING THE
3X #10 X 1.00" LONG TAMPER RESISTANT WOOD SCREWS AS
SHOWN **MAKING SURE IT IS IN THE CORRECT ORIENTATION BEFORE
YOU SCREW IT TO THE COUNTER.**
- 5. ASSEMBLE THE **CUSTOMER'S CREDIT CARD MACHINE** TO THE **SWIVEL BASE**
BY SLIDING IT ONTO THE **3X KEYHOLE STANDOFFS** AS SHOWN.
THIS ENSURES THE PROPER FUNCTION OF THE **HINGED REAR LOCKING BRACKET.**
- 6. MOVE **HINGED REAR LOCKING BRACKET** INTO PLACE AND LOCK AS SHOWN
IN **DETAIL B.**
- 7. INSTALL THE **CABLE CLIP** AS SHOWN USING THE **#8-32 X .25" LONG PHILLIPS
SCREW** AS SHOWN.



(UNLOCKED) (LOCKED)

DETAIL B

| | | | | | | | | | |
|---|--|------------------|---|--------------------------------------|-----------------------|-------------|----------|-----|-------|
| DWG. NO. PTM-VFN-02 | | REV. A | TITLE LOW CONTOUR STAND 8-90 DEGS LOCKING ANTI-SKIMMING VERIFONE M440/M450 | <div>HAVIS</div> SHEET 1 OF 1 | A | | 05/06/24 | JVT | JVT |
| DRAWN J. TERVEER | | DATE 5/6/2024 | | | REV. | DESCRIPTION | DATE | BY | CHK'D |
| THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF HAVIS, INC. AND REPRODUCTION IN PART OR IN WHOLE WITHOUT THE WRITTEN PERMISSION OF HAVIS, INC. IS PROHIBITED. | | | | | CUSTOMER INSTRUCTIONS | | | | |